



World's Best Flat Screen Mounting System
Less parts • Highest integrity • Easy installation

Required Tools:

Power Drill
1/2" Socket and Ratchet
Stud Finder
Tape Measure
Pencil

Small Mount Hardware:

(1) 3/16" Drill Bit	(1) 4mm Hex
(2) 5/16" x 2 1/2" Lag Bolts	(2) M4 x 22mm
(2) 5/16" x 11/16" Washers	(2) M4 x 16mm
(2) M6 x 25mm	(1) 2.5mm Hex
(2) M6x 18mm	(4) 6mm Delrin Spacer

Instructions:

1. Position the wall mount bracket on the wall in the desired mount location. The wall mount bracket should be oriented with the angled side pointing up and the bubble level visible. Mark the wall at the center of the wall mount bracket.



2. Locate the two closest vertical studs on either side of the mark made in Step 1. It is recommended that the wall mount be secured to a minimum of two studs if mounted on a wooden frame wall. If framing of the wall is constructed of another material, consult a licensed contractor for the best anchoring options.



3. Once the studs are located, drill a hole 2 1/2" deep into one of the studs using the drill bit supplied. Insert one of the anchor bolts through the bracket into the wall and tighten enough to hold the bracket and still allow the bracket to be moved.



WARNING: A minimum of two (2) Lag Bolts **MUST** be used to install the Mighty Mount to the wall. Each Lag Bolt **MUST** be securely fastened to **THE CENTER** of the wall studs, in both mounting locations. Please contact and use a professional installer if necessary.

4. Using the integrated level in the wall mount, adjust the mount bracket until level and mark the location of the next hole (should correspond to the second stud location). After marking the hole, move the mount to allowing drilling of the second hole and drill as in Step 3. Insert the second bolt through the bracket and into the wall. Securely tighten both bolts.



WARNING: A minimum of two (2) Lag Bolts **MUST** be used to install the Mighty Mount to the wall. Each Lag Bolt **MUST** be securely fastened to **THE CENTER** of the wall studs, in both mounting locations. Please contact and use a professional installer if necessary.



World's Best Flat Screen Mounting System
Less parts • Highest integrity • Easy installation

Instructions Continued:

5. Lay the TV on flat surface face down to access the back mounting holes.

5



6. Attach (2) TV mount brackets to back side of TV using hardware supplied. Angled side of brackets should be mounted near the top side of the TV and face down. If needed, spacers have been provided, for you to use if needed on the back panel. If more spacers are needed please contact Nemat Inc.

6



7. Ensure all appropriate cables/wires have been connected for your specific TV system.

7



8. Lift the TV and position the angled part of the TV brackets to drop down over the angled part of the wall mount bracket. Once the TV mount brackets are securely seated on the wall mount, slide the TV either way to the desired location.

8



For technical support:
Nemat Inc • 19225 Road 24 • Madera, CA 93638
Toll Free 877.540.6716 or info@nemat.com